

**MONSTER®**  
**INDOOR/OUTDOOR**  
 Music that Suits Your Lifestyle!

Quick Start Guide

For complete operational guidelines, please refer to your user manual.

Basic Set up

**1** Connect the AC Power



- Connect the included AC Cable to each speaker
- Plug cord into wall outlet.
- Charge battery for approximately 10 hours before you start using the unit for the first time.

**2** Charge built-in batteries on the Monster 249



- By connecting the AC power, battery will be charged and Red LED will turn on.
- Red LED indicator means that unit is plugged in and charging.
- ⊖ Red LED indicator will turn off when unit is fully charged.
- ⊕ If Red LED indicator is flashing, this means that the battery levels are low and need charging.

**3** Bluetooth pairing with NFC enabled device

- Turn on NFC function on your Bluetooth enabled device.
- Place your Bluetooth device on the silkscreen "NFC" on the top surface of the Monster 249 speaker
- Confirm Bluetooth connection on your Bluetooth device.
- Blue LED indicator on the Monster Power will be solid.




- Once paired you can play audio from your Bluetooth device and audio can be heard through the speaker.

Note: If pairing won't complete automatically, your Bluetooth device might not be NFC enabled.

Skip to Step 5 so that you can manually complete pairing.

Bluetooth® Connection

**4** Manual Bluetooth Pairing



Press and hold BT button for 2 seconds



- Place the Monster 249 speaker and your Bluetooth device so that they are no more than 3 feet apart.
- Press and hold the Bluetooth button on the Monster 249 speaker for 2 Seconds to enter into Bluetooth pairing mode.
- Bluetooth LED will flash rapidly.

- Set your Bluetooth device to search for Bluetooth connections. You will recognize the speaker by its Bluetooth name "Monster 249 speaker"



EZ-Play allows you to easily connect up to 8 speakers wirelessly and broadcast your favorite music to all speakers simultaneously to create an Audio Surround Experience indoors or outdoors.


•EZ-Play technology also available on Monster Tower



**5** EZ-Play wireless connection

- Press and hold the "EZ Play" button" on the speaker for 2 seconds to send a connection request to a second unit.

NOTE: This function can only be completed with other EZ Play speakers.



- EZ Play Amber LED will pulse on the transmitting speaker.
- Press and hold the "EZ Play" button on the transmitting speaker for 2 seconds to scan for a connection request from the receiving speaker.
- EZ Play Amber LED on both units will turn solid upon completion of connection.