

MONSTER[®] NOMAD


PORTABLE INDOOR /OUTDOOR WIRELESS SPEAKER

Quick Start Guide

For complete operational guidelines, please refer to your user manual.

Basic Set up

1 Connect the AC Power



- Connect the included AC Cable to the speaker
- Plug cord into a wall outlet.
- Charge battery for approximately 6 hours in power off mode before you start using the unit for the first time

2 Charge the Unit



- By connecting the AC power, the battery will begin to charge. Switch the Power switch (ON/OFF) to ON position to power on Speaker
- If **Red LED** indicator is flashing, this means that battery levels are low and need charging.
- If **Red LED** indicator is on, this means the battery level is full

3 FM / USB Charging on the Nomad



A. Listening to FM radio

- Press the "Source" button to select FM source, the radio station frequency is displayed on screen.
- Press and hold (◀ or ▶) to search a station with strong reception automatically.

B. Store your favorite four radio stations manually

- Tune to a radio station.
- Press and hold a number key (1-4) to enter programming mode; the corresponding number blinks on the screen; and your station is saved
- Repeat above step 1-2 to store additional presets

Bluetooth[®] Connection

4 Manual Bluetooth Pairing

- Place the speaker and your Bluetooth device so they are no more than 3 feet apart.
- Press the source button until "BT" Mode is displayed on screen.
- Press and hold button on Speaker for 2 seconds to enter into Bluetooth pairing mode. BT Blue LED will flash. Make sure Bluetooth function on your Bluetooth device is ON.
- Set your Bluetooth device to search for Bluetooth devices. You will recognize the unit by its Bluetooth name Monster Nomad



Bluetooth Pairing

- Bluetooth LED turns solid once a Bluetooth device has been paired.

Bluetooth Blue LED Indicator
(Flashing to **Steady On**)



Pairing Using NFC

- Turn on NFC function on your Bluetooth enabled device.
 - Place your Bluetooth device on the "NFC" on the right side of the Monster Nomad handle
 - Confirm Bluetooth connection on your Bluetooth device.
- Note: 1. Ensure the unit is compatible with Bluetooth before pairing via NFC
2. The Blue LED indicator will become when NFC pairing is successful.
- Once paired you can play audio from your Bluetooth device.

5 Connect Microphone



A. Connect Microphone

- Plug your microphone to the input labeled "MIC/Guitar" above the Volume knob
- Once the microphone is plugged in through the supplied Mic/Guitar converting the header (6.5mm to 3.5mm) select the "MIC/Guitar" button
- Now control your microphone volume on the smaller knob on the far left of the dashboard of the speaker

*Make sure your microphone is also switched to "On"