

# ROCKIN' ROLLER<sup>®</sup> 4

## QUICK START GUIDE

**IMPORTANT:** Before first use, charge for ~6 hours.

### Power/Charging

- Flip the switch UP to turn ON the speaker.
- Flip the switch DOWN to turn OFF the speaker.



- Connect the POWER INPUT port to an external power source using the included power cord.



**DO NOT use the speaker's AC Outlet port**  
– it will not charge or power the speaker.

### Bluetooth Pairing

- 1 Place your mobile device within 3 feet of the speaker.  
Make sure Bluetooth is enabled on your mobile device.



- 2 Press the BLUETOOTH button to set the speaker to Bluetooth mode.

(Press)



- 3 Select "Monster RR4" on your mobile device to pair with the speaker.



### True Wireless System (TWS)

Wirelessly connect two Rockin' Roller 4 speakers together:


- 1 Place two Rockin' Roller speakers within 10 feet of each other.



- 2 Connect your music device to one of the speakers via BLUETOOTH.  
Leave the second speaker in BLUETOOTH mode without connecting to a device.



- 3 Press the TWS pairing button on both speakers to activate TWS pairing. The speakers will automatically connect with each other.



**~30 feet max connection range after paired.** Moving devices outside this range may cause disruption or signal loss.